

COMPAQ	
S1	Evo: N1000v, N1015v, N1020v
	Presario: 900 Series, 1500 Series, N1050V
S5	Presario: 1110, 1115, 1120, 2100 series, 2500 series, 3005, 3015, 3017, 3019, 3020, 3080
DELL	
S10	Inspiron: 2500, 2600, 2650, 3700, 3800, 4000, 4150, 5000, 7500, 8000, 8100
	Latitude: X200(Power Only), C400, C410, C500, C510, C600, C610, C640, C800, CP, CPi, CPT, CPx, CS/CSx, LM
FUJITSU	
S5	Lifebook: C1020
S11	LifeBook: 270Dx, 280Dx, 420D, 435Dx, 500, 520D, 520T, 530T, 531T, 535Tx, 555T, 565Tx, 585Tx, 585Tx1, 635T, 635Tx, 635Tx1, 655Tx, 656Tx, 675Tx, 690Tx, 735Dx, 755Tx, 756Dx, 765Tx, 770Tx, 790Tx, 985Tx, 990Tx2, A4170, B112, B142, B2, B2130, B2131, B2175, B-2545, B-2562, B-2566, B2610, B2620, B2630, B3010D, B3020, B3020D, C340, C350, C352, C353, C360, C-4120, C-4235, C-5130, C-5235, C-6177, C-6320, C-6330, C-6525, C-6535, C-6537, C-6547, C-6556, C-6557, C-6577, C-6581, C-6591, C-6611, C-6631, C-6651, C-7631, C-7651, C-7661, E2010, E330, E340, E342, E350, E351, E335, E360, E362, E370, E380, E-5140, E-5320, E-5520, E-6150, E-6520, E-6530, E-6540, E-6541, E-6550, E-6555, E-6556, E-6557, E-6570, E-6571, E-6575, E-6595, L440, L470, P-1000, P-1032, P-1035, P-1110, P-1120, P-2000, P-2040, P-2046, P-2110, P-2120, P-5010, P-5010D, P-5020, P-5020D, P-7010, P-7010D, S-2010, S-2020, S-4510, S-4542, S-4546, S-4572, S-5582, S6010, S6110, S6120, S6120D, S6210, S6220, S6231, T3010, T3010D
	Stylistic: CT2020, 3400, 3500, ST4110, ST4110P, ST4120, ST4120P, ST4121, ST5010, ST5010D, ST5011, ST5011D, ST5020, ST5020D, ST5021, ST5022,
	Celsius: Mobile H
	Stylistic LT: C-500, P-600
HP	
S5	Business Notebooks: NX9000, NX9005, NX9008, NX9010
	Pavillion: ze4000, ze4400 series, ze4500 series, ze4600, ze4601, ze4605, ze4610, ze4615, ze4630, ze4631, ze4700, ze4715, ze4717, ze4725, ze4800, ze4805us, ze5000, ze5100 series, ze5200 series, ze5300 series, ze5400 series, ze5500 series, ze5600 series, ze5700 series, zv5434RS
IBM	
S4	ThinkPad: 600E, 600X, 770E, 770ED, 770X, 770Z, A series, R series, T series, X series, Transnote
PANASONIC	
S4	Toughbook: CF29, CF-50, CF-73, CF-R1, CF-T1, CF-T2
S11	Toughbook: CF01, CF11, CF17, CF170, CF270, CF370, CF380, CF25, CF27, CF28, CF33, CF34, CF35, CF37, CF41, CF45, CF47, CF48, CF61, CF62, CF63, CF71, CF72, CF-M34, CF-V25, CF-V41
SONY	
S11	Picturebook: C1X
	VAIO: B100B, C1MHP, GR100, GR100K, GR114EK, GR114MK, GR114SK, GR150K, GR170K, GR200, GR200K, GR200P, GR214CP, GR214EP, GR214MP, GR215MP, GR215SP, GR250, GR250K, GR250P, GR270, GR270K, GR270P, GR290, GR290K, GR290P, GR300, GR314MP, GR315MP, GR370, GR390, GR414SP, S260, S360, S150, S150P, S170, S270, SR11K, SR17, SR17K, SR1K, SR21K, SR5K, SR7K, SR9G, SRX41P, SRX51P, SRX51PA, SRX51PB, T140 series, T150 series, T160 series, T250 series, T270P/L, T340P/L, T350 series, T360 P/L, T370P/L, TR1A, TR1AP, TR2A, TR2AP1, TR2AP3, TR3AP1, TR3AP2, TR1, TR2, TR3, TR5GP, V505A, V505AC, V505AXP, V505B, V505BC, V505BX, V505BXP, V505D, V505DC1, V505DC11, V505DC1P7, V505DX, V505DXP, V505EXP, V505EC, V505ECP1, V505DC1PF, V505DC1P2, V505DC21, V505DC2P1, VX71P, X505, X505ZPKIT, X505ZPKIT2, Z1, Z1A, Z1AP1, Z1AP2, Z1AP3, Z1M, Z1R5P, Z1RA, Z1RAP1, Z1RAP2, Z1RAP3, Z1SP, Z1VAP1, Z1WAMP, Z1WAP1, Z1ZAP1, Z505AX, Z505AXP
S12	VAIO: 81, 705, 707, 717, 719, 729, 731, 735, 748, 800, 808, 812, 818, 838, C1XW, F Series, F150, F160, F180, F190, F250, F270, F280, F290, F304, F305, F309, F340, F350, F360, F370, F390, F400, F400LT, F403, F409, F420, F430, F450, F480, F480K, F490K, F520, F540, F540K, F560, F560K, F580, F580K, F590, F590K, F630, F660, F670, F680, F690, F701, F707, F709, F709K, F801, F801A, F807, F807K, F808K, F809K, FR102, FR105, FR130, FX series, GRX series, GRX series, NV100, NV105, NV109M, NV170, NV190, NV200, NV209, NV309, NVR23, PG32, QR10, QR20, R500, R505CT, R505D, R505DT, R505J, R505T, R505TE, R505TEK, R505TS, R600HEK, R600HEP, R600HFPD, R600HMPD, R600MX, X18, X29, X9, XE17, XE7, XG18, XG19, XG28, XG28K, XG29, XG38, XG39, XG39K, XG500, XG700, XG9, Z505, Z505FA, Z505GA, Z505GAH, Z505GAM, Z505HE, Z505HS, Z505HSK, Z505JE, Z505JEK, Z505JS, Z505JSK, Z505LE, Z505LEK, Z505LS, Z505LSK, Z505R, Z505RX, Z505S, Z505SX, Z600HEK, Z600LEK, Z600NE, Z600NEK, Z600RE, Z600TEK
TOSHIBA	
S5	Satellite: 1110 series, 1115-S103, 1130 series, 1135-S125, 1905-S277, 1955-S801, 2430 series, 2435-S255
S6	Qosimo: E15-AV101, F15-AV201, F25-AV205