

AVERATEC	
3	3120V, 3150H, 3150HD, 3150HS, 3150HW, 3150P, 3200, 3220H, 3220H1, 3225HS, 3250H1, 3250HX, 5100, 5110H, 5110P, 5110HX, 6240, AV3500T60, AV3500T80, AV6210HX80, AV6200H60, AV6210X60, AV1050-EB1, AV3250HS, AV3250PX, AV3255P1, AV3270-EE1, AV3270-EH1, AV3360EG1, AV3360EH1, AV3715-ED1, AV3715-EH1, AV4115-EE1, AV4155-EH1, AV4265-EH1, AV4270-EH1, AV5500, AV6235
Compaq	
2	Armada: 110, E500, E500S, E700, M300, M700, V300
	Evo: N110, N150, N200, N400c, N410c, N600c, N610c, N620C, N800c, N800w, N800w
	Presario: 305, 2200 series, 2800 series, 2900 series, M2000 series, V1000 Series, V1100 Series, V2000 series, V2100 series, V2200, V4000 series, V4100 Series, X1000 Series, X1105EA, X1110EA, X1115EA, X1140EA, X1155EA, X1200 Series, X1300 Series, X1460, X1480, B3800
	Prosignia: 170, 190
3	Evo: N115, N160, N180
	Presario: 700 series, 800 series, 1000 series, 1200 series, 1400T, 1600 series, 1700 series, 180C series, 2700 series, 12XL, 14XL, 1600s, 16XL, 17XL, 1800t, 18XL, 2700 series
	Prosignia: 150
DELL	
3	Inspiron: 3000, 3200, 3500, 7000
9	Inspiron: 2500, 2600, 2650, 3700, 3800, 4000, 4150, 5000, 7500, 8000, 8100
	Latitude: X200(Power Only), C400, C410, C500, C510, C600, C610, C800, C810(Power Only), CP, CPi, CPl, CPx, CSiCSx, Li, LM
20	Inspiron: 300M, 500M, 510M, 600M, 700M, 6000, 8600, 9200, 9300 (Power Only)
	Latitude: D Series, X300, L100 (Power Only)
	Precision: M20, M60, M70 (Power Only)
Fujitsu	
3	LifeBook: A1010, Cxxx7, C1010, C1020, C1110, C1211D, C2010, C2110, C2111, C2210, C2220, C2230, C2240, C2310, C2320, C2330, C2340, C6xx5, Cxxx7, E2010, E4010, E4010D, E66xx, E6624, E6634, E6644, E6654, E6664, E7010, E7110, E8010, E8010D, E8020, S7010, S7010D, S7011, T4010, T4010D, Amilio L
11	LifeBook: 420D, 500, 520D, 520T, 530T, 555T, 270Dx, 280Dx, 435Dx, 531T, 565Tx, 585Tx, 585Tx1, 635T, 635Tx, 635Tx1, 655Tx, 656Tx1, 675Tx, 690Tx, 735Dx, 755Tx, 756Dx, 765Tx, 770Tx, 790Tx, 985Tx, 990Tx2, A4170, B112, B142, B2, B2130, B2131, B2175, B-2545, B-2562, B-2566, B2610, B2620, B2630, B3010D, B3020, B3020D, C340, C350, C352, C353, C360, C-4120, C-4235, C-5130, C-5235, C-6177, C-6320, C-6330, C-6525, C-6535, C-6537, C-6547, C-6556, C-6557, C-6577, C-6581, C-6591, C-6611, C-6631, C-6651, C-7631, C-7651, C-7661, E2010, E330, E340, E342, E350, E351, E335, E360, E362, E370, E380, E-5140, E-5320, E-5520, E-6150, E-6520, E-6530, E-6540, E-6541, E-6550, E-6555, E-6556, E-6557, E-6570, E-6571, E-6575, E-6595, L440, L470, P-1000, P-1032, P-1035, P-1110, P-1120, P-2000, P-2040, P-2046, P-2110, P-2120, P-5010, P-5010D, P-5020, P-5020D, P-7010, P-7010D, S-2010, S-2020, S-4510, S-4542, S-4546, S-4572, S-5582, S6010, S6110, S6120, S6120D, S6210, S6220, S6230, S6231, T3010, T3010D
	Stylistic: CT2020, 3400, 3500, ST4110, ST4110P, ST4120, ST4120P, ST4121, ST5010, ST5010D, ST5011, ST5011D, ST5020, ST5020D, ST5021, ST5021D, ST5022, ST5022D
	Celsius: Mobile H
	Stylistic LT, C-500, P-600
	Tablet: ST41xx A/P, ST501x A/P
GATEWAY	
3	Solo: 1100, 1150, 1200, 1400, 1450, 2150, 2500, 2550, 3100, 3150, 5150, 5300, 5350, 9100, 9150, 9300, 9500, 9550
	405E, 405X, 400SD4, 400VTX, 450ROG, 450SX4, 600YG2, 600YGR, M305, M500, 3018GZ, 3040GZ, 3520GZ, 3522GZ, 3550GH, 3550GZ, 4012GZ, 4024GZ, 4025GZ, 4026GZ, 4028GZ, 4520GZ, 4530GH, 4530GZ, 4535GZ, 4536GZ, 4538GZ, 4540GZ, 4542GP, 6010GZ, 6018GZ, 6510GZ, 6518GZ, 6520GZ
HP	
2	Tablet: TC1000, TC1100
	Desktop Notebooks: NW8000, NC8000
	Business Notebooks: NC4000, NC4010, NC6000, NX6120, NX7000, NX7010, NX9020, NX9030, NX9040
	Pavilion: ZT3000, ZT3001US, ZT3000LA, ZT30XX series, ZT31XX series, ZT32XX series, ZT33XX series, ZE20XX series, ZE49XX series, DV10XX series, DV11XX series, DV12XX series, DV14XX series, DV4000 series, DV4100 series
3	Omnibook: 500, 510, 900, 900B, 2100, 2103, 2105, 3000, 3100, 3101, 4000C, 4100, 4101, 4103, 4105, 4150B, 6000B, 6000C, 6100, VT6200, 7100, 7103, 7150, 900b, N3000, v16200, xe series, xt series
	Pavilion: 2105, 3101, 4101, 4103, 4105, 5159, N3100 series, N3200 series, N3300 series, N3400 series, N5000 BTCO, N5100 series, N5200 series, N5300 series, N5400 series, N5511L, N5584, N6190, N6195, N6300 series, N6400 series, xf series, xh series, xt series, xu155, xulzu BTCO, xz series, ZE1000, ZE11xx series, ZE12xx series, ZE41xx series, ZE42xx series, ZE43xx series, zt1000, IB BTCO, ZT11xx series, ZT12xx series, ZE1331, zu1155, zu175, zu1175
IBM	
4	
	ThinkPad: 600E, 600X, 770E, 770ED, 770X, 770Z, A series, R series, T series, X series, Transnote
Panasonic	
4	Toughbook:CF-R1, CF-T1, CF-T2
11	Toughbook: CF01, CF11, CF17, CF170, CF270, CF370, CF380, CF25, CF27, CF28, CF33, CF34, CF35, CF37, CF41, CF45, CF47, CF61, CF62, CF63, CF71, CF-M34, CF-V25, CF-V41
Sony	
11	Picturebook: C1X
	VAIO: B55T, B100B, C1MHP, C1MT, C1MT1, GR100, GR100K, GR114EK, GR114MK, GR114SK, GR150K, GR170K, GR200, GR200K, GR200P, GR214CP, GR214EP, GR214MP, GR215MP, GR215SP, GR250, GR250K, GR250P, GR270, GR270K, GR270P, GR290, GR290K, GR290P, GR300, GR314MP, GR315MP, GR370, GR390, GR414SP, S260, S360, S150, S150P, S170, S270, SR11K, SR17, SR17K, SR1K, SR21K, SR5K, SR7K, SR9G, SRX41P, SRX51P, SRX51PA, SRX51PB, T140 series, T150 series, T160 series, T250 series, T270, T340, T350 series, T360P/L, T370P/L, TR1A, TR1AP, TR2A, TR2AP1, TR2AP3, TR3AP1, TR3AP2, T171P, TR1, TR2, TR3, TR5GP, V505A, V505AC, V505AXP, V505B, V505BC, V505BX, V505BXP, V505D, V505DC1, V505DC11, V505DC1P7, V505DX, V505DXP, V505EXP, V505EC, V505ECP1, V505DC1PF, V505DC1P2, V505DC21, V505DC2P1, VX71P, X505, X505ZPKIT, X505ZPKITZ, Z1, Z1A, Z1AP1, Z1AP2, Z1AP3, Z1M, Z1R5P, Z1RA, Z1RAP1, Z1RAP2, Z1RAP3, Z1SP, Z1VAP1, Z1WAMP1, Z1WAP, Z1ZAP1, Z505AX, Z505AXP
12	VAIO: 81, 705, 707, 717, 719, 729, 731, 735, 748, 800, 808, 812, 818, 838, A17GP, A19GP, A29GP, A29TP, A130, A140, A150, C1XW, F Series, F150, F160, F180, F190, F250, F270, F280, F290, F304, F305, F309, F340, F350, F360, F370, F390, F400, F400LT, F403, F409, F420, F430, F450, F480, F480K, F490K, F520, F540, F540K, F560, F560K, F580, F580K, F590, F590K, F630, F660, F670, F680, F690, F701, F707, F709, F709K, F801, F801A, F807, F807K, F808K, F809K, FR102, FR105, FR130, FX series, GRS series, GRX series, NV100, NV105, NV109M, NV170, NV190, NV200, NV209, NV309, NVR23, PG32, QR10, QR20, R500, R505CT, R505D, R505DT, R505J, R505T, R505TE, R505TEK, R505TEK, R600HEK, R600HEP, R600HFPD, R600HMPD, R600MX, X18, X29, X9, XE17, XE7, XG18, XG19, XG28, XG28K, XG29, XG38, XG39, XG39K, XG500, XG700, XG9, Z505, Z505FA, Z505GA, Z505GAH, Z505GAM, Z505HE, Z505HS, Z505HSK, Z505JE, Z505JEK, Z505JS, Z505JSK, Z505LE, Z505LEK, Z505LS, Z505LSK, Z505R, Z505RX, Z505S, Z505SX, Z600HEK, Z600LEK, Z600NE, Z600NEK, Z600RE, Z600TEK
Toshiba	
3	Satellite/Dynabook Satellite: 1000, 1005, 1100, 1200, 1400, 1410, 1605, 1620, 1625, 1640, 1670, 1675, 1690, 1695, 1700, 1710, 1715, 1730, 1735, 1750, 1755, 3000 series, 3005, L15, M30X series, M35X series, M40X series, M45X series
	Equium: L10-142, L10-200
	Portégé: 2000, 2010, 4000, 4005, 4010, 3500 Tablet, 3505 Tablet, 7000CT, 7010CT, 7020CT, 7140CT, 7200CT/Cte, 7220Cte, A100, A200, M100, M200, M205, M300, R100, R150, R200, RS100, S100 series
6	Satellite/Dynabook Satellite: 200, 220, 300, 310, 320, 330, 1400, 1405, 1410, 1415, 1555, 1800, 1805, 1830, 1850, 1860, 1870, 2000, 2010, 2100, 2060, 2065, 2100 series, 2200 series, 2400, 2405, 2410, 2415, 2500 series, 2600 series, 2700 series, 2800, 2805, 4000 series, 4100, 5000, 5005, 5100 series, S105, S200, S205, A10, A11 series, A15, A50, A55, J32 series, J31 series, J30 series, J12 series, J11 series, L10 series, T11 series, T10 series, M20, M30, M35, M40 series, M45 series, M55 series, R10-S802TD, R15-S822, S4, S5, S6
	Satellite Pro: 430, 440CDT/CDX/CS, 445CDT/CDX, 460CDT/CDX, 465CDT/CDX, 470CDT, 480CDT, 490CDT/CDT, 520CDT, 550CDT, 2100, 4200, 4220, 4260DVD, 4280XDVD, 4300, 4600, 6000, 6070, 6100, A10, M10, M15, M30
	Tecra: S20CDT, S50CDT, TE2000, TE2100, TE2300, 8000, 8100, 8200, 9000, 9100, A1, A2, A3, A4, A5, M1, M2, M3, M4, M2V, S1, S2
Winbook	
3	J1, N, Si, Si2, X1, X2, X4, XL, XLI, XP, Z