


Print fun 4 x 6-inch photos almost anywhere

- Print stunning 4x6 photos without a PC
- Easily pack or carry this light weight compact printer.
- Get truly portable printing with optional rechargeable battery.¹



- Print beautiful 4 x 6-inch photos on the spot wherever you go, without a PC.
- Easily pack or carry this lightweight, compact printer—its tray folds up and snaps shut for travel.
- · Get truly portable printing, with an optional rechargeable battery, for up to 75 prints per charge.1
- Easily print a 4 x 6-inch photo at home, parties or almost anywhere—in as fast as 53 seconds.
- Print directly from select camera phones, notebook PCs and more, with an optional wireless adapter.²

The easy way to print your perfect HP photos.

- Print photos directly from PictBridge-enabled cameras or memory cards³—no PC required.
- Bypass the PC—preview photos on a 1.5-inch image display, and then print only the ones you want.
- Automatically remove red eye, sharpen photos and improve color, using a unique HP Photo Fix button.
- Make it easier to print on the go, using optional HP accessories, including carrying cases.
- Crop a photo on the image display to make a 4 x 12-inch panorama print—no PC needed.



Lab-quality, water⁵-and fade-resistant⁶ photos

- Make memories last-print lab-quality photos that resist fading for generations.6
- Photos dry instantly, so you can handle them right from the printer—without smudging or smearing.5
- Rely on HP, PC Magazine Reader's Choice winner for service and reliability for 14 straight years.

¹HP Photosmart Internal Battery for Compact Photo Printers not included. Please purchase separately. Number of prints per charge may vary.

² Bluetooth wireless adapter not included. Supports camera phones with Bluetooth wireless technology. Visit http://www.hp.com/support/bluetooth for a list of compatible devices.

³Supports CompactFlash, SmartNedia, Memory Stick, Secure Digital/MultiMediaCard and xD-Picture Card. Also supports Memory Stick Duo (with adapter) and Mini SD (with adapter). Memory cards not included, please purchase separately.

⁴Printer accessories not included. Please purchase separately.

⁵Smudge- and water-resistant only when printed using HP Advanced Photo Paper and HP 110 Tir-color Inkiel Print Cartridge with HP Vivera Inks, not available in 4 x 12-inch panorama size.

110 Tri-color Inkjet Print Cartridge with Hr vivera tinks, not available in 2 in a panorama size.

*Up to 50 years based on Wilhelm-Research.com light fade testing under glass using the HP 110 Tri-color Inkjet Print Cartridge with HP Vivera Inks on HP Advanced Photo Paper. For more information on water resistance, please visit http://www.hp.com/go/printpermanence.

*Supports Memory Sitck Duo (with adapter) and Mini SD (with adapter). Memory cards and adapters not included, please purchase separately.

Not included. For information on compatibility, please go to http://www.hp.com/support.



Technical specifications

HP Thermal Inkjet
HP Adaptive Lighting, HP Auto Red-eye Removal
Color: Up to 4800 x 1200 dpi; Black: Up to 1200 x 1200 dpi
As fast as 53 sec (with border, when printing from PC)
Yes (memory cards, PictBridge cameras)
1 USB, 1 PictBridge, 4 memory card
CompactFlash, Memory Stick, SmartMedia, Secure Digital/MultiMediaCard and xD-Picture Card. Also supports Memory Stick Duo (with adapter) and Mini SD (with adapter). Memory cards, iPODs and Flash drives not included. Please purchase separately.
Optional, with HP bt450 Bluetooth Wireless Printer and PC Adapter
Yes (up to 4 x 12 in)
20-sheet input tray; input capacity: Up to 20; Output capacity: Up to 20
Types: Photo paper, index cards; Sizes: 4 x 6 in, 4 x 6.5 in, 4 x 8-in photo card, 4 x 12-in panorama; Weight: Up to 110 lb index
32 MB
1.5-in LCD (color graphics)
5 front-panel buttons (On/off, HP Photo Fix, Print, Cancel, OK)

Dependent upon type, print mode and approximate figures. Exact speed will vary depending on the system configuration, software program and photo density.

Compatible Operating System

Windows 98 SE, 2000, Me, XP Home, XP Professional, XP Professional x64 Edition; Mac OS X v 10.3.9 and higher Minimum System Requirements

PC: Pentium II (or equivalent) or higher; 64 MB RAM (256 MB recommended); 200 MB available hard disk space (450 MB recommended); SVGA 800 x 600 monitor with 16-bit color; Windows 98 SE, 2000, Me, XP Home, XP Professional, XP Professional x64 Edition; Internet Explorer 5.01 (SP2 or higher); 4x CD-ROM drive; USB port and USB cable (not included); Adobe Acrobat Reader 5 or higher recommended; Internet access recommended; Mac: Mac OS X v 10.3.9 and higher; G3 processor or compatible (G4 or higher recommended); 128 MB RAM (256 MB or higher recommended); 400 MB available hard disk space for software installation; HP Memories Disc Creator Software, requires CD writer and 700 MB of available hard disk space; Internet Explorer 5.01 (SP2 or higher); 4x CD-ROM drive; USB port and USB cable (not included); Adobe Acrobat Reader 5 or higher recommended; Internet access recommended

Maximum Operating Temperature (Fahrenheit); 32 to 113° F (0 to 45° C); Recommended Operating Temperature (Fahrenheit): 59 to 95° F (15 to 35° C); Temperature Storage Range (Fahrenheit): -22 to 149° F (-30 to 65° C); Operating Humidity: 5 to 95% RH

Acoustics

Power Emissions (active, printing): 5.5 B(A); Pressure Emissions (active): 55 dB(A)

Power Supply Type: External power supply module, optional internal lithium ion battery (not included, sold separately); Input voltage: 100 to 240 VAC (+/- 10%), 50/60 Hz (+/- 3 Hz); Power Consumption (maximum): 12 watts maximum; Battery Type (optional): Lithium ion (not included, sold separately); Battery Life: Up to 75, 4 x 6-in photos per charge (with optional HP Internal Battery for HP Compact Photo Printers);

Dimensions (W x D x H)/Weight

8.7 x 4.6 x 4.6 in (220 x 116 x 116 mm)/2.6 lb (1.17 kg)

One-year limited hardware warranty backed by HP Customer Care, service and support; one-year technical phone support, plus a toll-free number

Ordering information

Whats In the Box?

- HP Photosmart A516 Compact Photo Printer
- HP 110 Tri-color Inkjet Print Cartridge (5 ml)
- Power module with cord
- User's Guide, Setup Poster
- HP Photosmart Premier software

HP Product	Part Numb
HP Photosmart A516 Compact Photo Printer	Q7021A
Replacement Ink Cartridges	
HP 110 Tri-color Inkjet Print Cartridge, 5 ml	CB304A
HP Business Communication Paper & Film	
HP Photo Papers	
HP Creative Papers	
Accessories	
HP USB Cable	C6518A
HP bt450 Printer and PC Adapter with Bluetooth Wireless	Q6398A
	HP Photosmart A516 Compact Photo Printer Replacement Ink Cartridges HP 110 Tri-color Inkjet Print Cartridge, 5 ml HP Business Communication Paper & Film HP Photo Papers HP Creative Papers Accessories HP USB Cable

HP Internal Battery for HP Compact Photo Printers Q5599A HP Photosmart Metro Style Carrying Case for Compact Photo Q8504A Q8505A

HP Photosmart Carrying Case for Compact Printers HP Photosmart DC Car Adapter Q3448A













HP is a registered trademark of the Hewlett Packard Company. All other trademarks are the property of their respective owners. Microsoft and Windows are registered trademarks of Microsoft Corporation. This listing of non-HP products does not constitute an endorsement by Hewlett Packard Company. © 2006 The information contained herein is subject to change without notice and is provided "as is" without warranty of any kind. HP shall not be liable for technical or editorial errors or omissions contained herein.



² Power requirements are based on the country/region where the printer is sold. Do not convert operating voltages. This will damage the printer and void the product warranty.